

Device type with status	Icon
Root	
Device disconnected	
Installation (Message Broker)	
Initialized	
Device disconnected	
Device Manager	
Initialized	
Device disconnected	
Bus controller	
Initialized	
Uploading persons	
Failure	
Configuration error	
Device disconnected	
Central unit	
Downloading history	
Uploading persons	
Bypass	
Communication lost	
Tamper	
Failure	
Configuration error	
Device disconnected	

Device type with status	Icon
Group	
Armed	
Alarm	
Rearm	
Bypass	
Failure	
Test	
Configuration error	
Device disconnected	
Card reader	
Tamper	
Failure	
Configuration error	
Device disconnected	
Keyboard	
Tamper	
Failure	
Configuration error	
Device disconnected	
Device	
Tamper	
Failure	
Configuration error	
Device disconnected	
Laser scanner	
Armed	
Alarm	
Device disconnected	

Device type with status	Icon
Sensor	
Centre sensor	
Dual type sensor	
Emergency button	
Glass break sensor	
Infra sensor	
Shock sensor	
Magnetic sensor	
Fire sensor	
Multisensor	
Normal	
Alarm	
Tamper	
Failure	
Bypass	
Activity	
Configuration error	
Device disconnected	
Fire sensor	
Fire button	
Thermal differential detector	
Temperature detector	
Fire detector above Suspended ceiling	
Fire detector in floor	
Normal	
Fire alarm	
Failure	
Bypass	
Test	
Configuration error	
Device disconnected	

Device type with status	Icon
Input	
Open	
Bypass	
Failure	
Configuration error	
Device disconnected	
Output	
Open	
Bypass	
Failure	
Configuration error	
Device disconnected	
Door	
Tamper	
Open	
Secured	
Locked	
Failure	
Configuration error	
Device disconnected	
Lift door	
Tamper	
Open	
Secured	
Locked	
Failure	
Configuration error	
Device disconnected	
Ramp	
Open	
Configuration error	
Device disconnected	

Device type with status	Icon
Lift	
Configuration error	
Device disconnected	
Parking	
Communication lost	
Configuration error	
Device disconnected	
Videocamera	
Configuration error	
Video signal lost	
Video input	
Configuration error	
Video signal lost	
Video output	
Configuration error	
Device disconnected	
Track list	
Device disconnected	
Track	
Device disconnected	
Audio input	
Open	
Configuration error	
Device disconnected	
Audio output	
Open	
Configuration error	
Device disconnected	

Device type with status	Icon
Group of audio outputs	
Open	
Configuration error	
Device disconnected	
Replication	
Data ready for confirmation	
Replication task	
Data ready for confirmation	
Replication in progress	